


Get the most out of your Phonak CROS B system



Phonak CROS B
on poorer hearing ear

Phonak Behind hearing aid on
better hearing ear

Benefits of performance level

Premium	<ul style="list-style-type: none"> • Understand in noisy situations (activated automatically) • Understand in echoey places • Understand in the car • Comfort in noisy situations • Restore sound awareness from the poorer hearing ear • Understand in quiet situations
Advanced	<ul style="list-style-type: none"> • Understand in noisy situations (activated manually) • Comfort in noisy situations • Restore sound awareness from the poorer hearing ear • Understand in quiet situations
Standard	<ul style="list-style-type: none"> • Comfort in noisy situations • Restore sound awareness from the poorer hearing ear • Understand in quiet situations
Essential	<ul style="list-style-type: none"> • Restore sound awareness from the poorer hearing ear • Understand in quiet situations

Phonak CROS B features at a glance

Phonak Belong hearing aid performance level	Premium B90	Advanced B70	Standard B50	Essential B30
Microphone mode Phonak hearing aid	StereoZoom (automatic)	StereoZoom (manual)	UltraZoom Standard	UltraZoom Essential
Microphone mode CROS B			Real Ear Sound*/ Omnidirectional	Omnidirectional
Channels	20	16	12	8
Automatic programs	5	4	3	2

*RIC models only



Phonak CROS B-13



Phonak CROS B-312



Phonak CROS B-13 Custom



Phonak CROS B-312 Custom